



Kindly inspect the equipment for any signs of damage and verify that you have received all the equipments

Procedure for Calibration

Calibration is not required

Note

- Meter can be tested with a known ORP solution to check functionality of the electrode.
- Change a new battery when the display fades or flashes.

Procedure for Measurement

- Rinse the electrode with clean water and wipe it dry. Dip the electrode into sample solution to be measured. Stir gently and wait until a stable reading can be obtained.
- After measurement, rinse the electrode with clean water, and replace the protective cap.

Procedure for Maintenance

Battery replacement

- Loosen the battery compartment counterclockwise.
- 2. Remove the old Lithium battery CR2032 and note polarity.
- Replace the battery according to the polarity & close the battery compartment cap tightly.

Electrode replacement

- Unscrew the electrode collar clockwise, and remove it completely.
- Pull the electrode module out from the tester.
- 3. Plug in new electrode module into the tester socket carefully.
- Replace and tighten the electrode collar to make a good seal.